

TUB FEET INSTALLATION WITHOUT BAR

Tools Needed

- 11/16 Wrench •

Parts Included

- Rubber Shims(If Included) • 4 Dovetail Bolts • 4 Flat Washers • 4 Locking Washers • 4 Nuts •

For some tubs you will find letters inside your tub foot to correspond with letters on the bottom of your tub as a guide to foot placement. If these are not present on your tub use following as a general guide.

- A. Roll top tubs have the drain located at the end of the tub and tilt toward the drain so the two tallest feet must be attached on the end without the drain. The two shortest feet must be attached on the drain end.
- B. Double roll top and double slipper tubs have the drain located in the center of the tub so no tilt is necessary as the bottom is slanted toward the drain. All four feet should be the same.

1. Place tub upside down onto a soft cloth/blanket to prevent damage. (Note: For roll top tub slide under rim 2X4 wooden block to elevate the tub from one side. This will help turn the tub over when finished)
2. Once the tub is turned upside down slide a dovetail bolt into each mounting pod. **(Shown in image 1)**
3. Put foot onto the dovetail bolt. Secure foot by using locking washer and nut. (It is normal to have small gaps between foot and tub wall).
- 4 . Lift tub by the rim and turn onto its feet.
5. Loosen the bolts and let the tub settle into place on the feet. Tighten the bolts.
6. **Barclay tubs are leveled before shipment.** Your tub may need further leveling to adjust to your floor. Some models have built-in adjusters under each foot that can be used for leveling. For models without adjusters in the feet, shims can be used to level.

DO NOT LIFT TUB BY FEET

Note: Barclay installs tub feet and levels tubs before shipping. Some tubs have 2 short feet and 2 tall feet to provide the correct slant for drainage. If you remove the feet for any reason be sure to return them to the same position from which you removed them.

INSTALLATION INSTRUCTIONS

1. Using a mild detergent, clean the areas of the tub and pedestal where they will connect. Dry the areas with a soft cloth.



2. Remove any hardware (bolt caps, nuts and washers) from the bottom of the tub, if applicable, and set aside.
3. Apply a line of silicone to the pedestal where the tub will rest, as shown.



INSTALLATION INSTRUCTIONS

4. Carefully place the tub on the pedestal and press firmly into place. Allow the silicone to dry for at least 24 hours.



5. Once dry, turn the tub and over and re-attach the hardware. Be careful not to over-tighten the bolts.



6. Use the levelers on the pedestal to make any needed height adjustments.