Metal Drawer Box Installation Instructions for the MDB500-185-xxx



IMPORTANT:

Before you begin, make sure you familiarize yourself with all the parts and fully read the instructions.


CUSTOMER SERVICE:

Toll-free customer help line available weekdays between 7:00am and 6:00pm Central Time at 800-463-0660.

TOOLS NECESSARY:

Screw gun or Phillips screwdriver and tape measure. NOTE: If screw gun has a clutch, set to lowest setting so as not to over tighten and/or strip screws.


PARTS IDENTIFICATION:





| 1 | Drawer profiles: (L/R) | 2X |
|---|--------------------------------------|----|
| 2 | Cabinet profiles: (L/R) | 2X |
| 3 | Side cover plate | 2X |
| 4 | Front fixing-bracket screws (4 x 17) | 8X |
| 5 | Front fixing-bracket | 2X |

| Part Dimensions | | | | | |
|-----------------|----------------|-----------------|-------------------|--|--|
| Item No. | Nominal length | Internal drawer | Min. installation | | |
| | | length | length of drawer | | |
| MDB500-185-15GR | 381 mm | 364 mm | 399 mm | | |
| MDB500-185-18GR | 457 mm | 440 mm | 475 mm | | |
| MDB500-185-21GR | 533 mm | 516 mm | 551 mm | | |

Step 1 - Installation Dimensions







KB - Cabinet width LW - Internal cabinet width NL - Nominal length

Back panel height = 155 mmBack panel width = LW - 42 mm Bottom panel width = LW- 21 mm Bottom panel length = NL - 11 mm Bottom panel material depth = 16 mm

