CRAFTMADE^{TN} LODIE X1408 X1410

PLEASE READ AND SAVE FOR FUTURE REFERENCE.

CAUTION

1. Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

2. All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

GENERAL

Remove all parts and hardware from the box and make sure that none are missing by referencing the illustrations provided.

Bulbs Required (not included): 1 -Medium Base 100 Watt Max.

1-LIGHT SEMI FLUSHMOUNT

- 1. OUTLET BOX (NOT INCLUDED)
- 2. SUPPLY GROUND WIRE (not included)
- 3. WHITE SUPPLY WIRE(not included)
- 4. WIRE CONNECTORS
- 5. RIBBED(or WHITE)FIXTURE LEAD WIRE
- 6. MOUNTING PLATE
- 7. BLACK SUPPLY WIRE(not included)
- 8. RIBBED(or BLACK)FIXTURE LEAD WIRE
- 9. MOUTING SCREW
- 10. OUTLET BOX SCREWS and WASHERS
- 11. FIXTURE GROUND WIRE
- 12. CANOPY
- 13. FINIAL
- 14. GROND SCREW
- 15. GLASS SHADE
- 16. SOCKET RING
- 17. STEEL RING
- 18. STEEL RING SCREW

