

INSTALLATION INSTRUCTIONS

Sahara Body Spray
Part #: S090-

JACLO[®]
Confidence from start to finish.™



INSTALLATION

1. Nipple should protrude 7/16" from finished wall.
2. Screw body spray onto nipple.
3. Run water, check for leaks.

To learn more about JACLO's warranty, please visit [**jaclo.com**](http://jaclo.com)