



1. Install Kitchen Faucet (1) as shown and secure using Tie-Down Kit (2). Longer Threaded Rod (3) is also supplied for decks/ sinks thicker than 3/4".
2. Install Handle (4) and secure by tightening Set Screw (5) using 2.5 mm Allen Key (supplied).
3. Attach Flex Hoses (6) to the corresponding water supply valves (not supplied).
4. Install Hose Guide (7) and Washer (8) and secure by tightening Nut (9) from underneath.
5. Instal Flange (10) and secure by tightening (by hand) Flange Nut (11).
6. Connect Check Valve (12) to Flextube (13) and Flexhose (14).
7. Connect Hand Spray to the Flexhose (14). Make sure that both Washers (15) and (16) are installed.