



FINE BATHROOM INTERIORS

## Installation Instructions

**Important: Please read these instructions before starting work.**

1. Check that there are no buried pipes or cables before drilling holes. Take extreme care when using electrical equipment near water.
2. When mounting accessories onto a tiled surface, a piece of insulating tape applied to the surface will help to prevent drill slippage.
3. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
4. We recommend the use of a specialized drill bit when fixing accessories to tiled area.

### **Supplied Mounting hardware:**

Allen key, screws and wall plugs.

### **Mounting Instructions:**

1. Establish position for accessories, making sure there is sufficient room.
2. Using the supplied allen key, loosen the set screw in the upright post and remove the backplate. Remove the backplate cover to expose the mounting holes.
3. Hold the backplate in the required position, mark through with a pencil. If two backplates are necessary, measure the distance between the two post centers, ensuring the marks are horizontal by use of a carpenter's level.
4. Drill holes to a depth of 1" inch using a ¼" inch drill bit and insert the wall plugs so they are flush with the wall.
5. Fix the backplate to the wall with the screws provided. Replace the backplate cover, then the post, making sure that the set screw points directly downward before tightening with the provided allen key.

### **Care Instructions:**

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)

