



FINE BATHROOM INTERIORS

Installation Instructions

Important: Please read these instructions before starting work.

1. Check that there are no buried pipes or cables before drilling holes. Take extreme care when using electrical equipment near water.
2. When mounting accessories onto a tiled surface, a piece of insulating tape applied to the surface will help to prevent drill slippage.
3. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
4. We recommend the use of a specialized drill bit when fixing accessories to tiled areas.

Supplied Mounting hardware:

Allen key, mounting plate, screws and wall plugs.

Mounting Instructions:

1. Establish position for accessories, making sure there is sufficient room.
2. Hold the mounting plate in the required position, mark through with a pencil. If two backplates are necessary, measure the distance between the two post centers, ensuring the marks are horizontal by use of a carpenter's level.
3. Drill holes to a depth of 1" inch using a ¼" inch drill bit and insert the wall plugs so they are flush with the wall.
4. Fix the mounting plate to the wall with the screws provided. Secure the backplate cover on to the mounting plate, securing the upper position of the cover first, then making sure that the set screw points directly downward and seats correctly before tightening with the provided allen key.

Care Instructions:

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)

