

Mounting instructions

- 1 Clean the base thoroughly and let it dry for 10 minutes. *Do not use an oil based cleaner*
- 2 Remove the protective film
- 3 Apply the product in the desired location
- 4 Locate the product into position allowing 24 hours before use

