



FINE BATHROOM INTERIORS

## Installation Instructions

**Important: Please read these instructions before starting work.**

1. Check that there are no buried pipes or cables before drilling holes. Take extreme care when using electrical equipment near water.
2. When mounting accessories onto a tiled surface, a piece of insulating tape applied to the surface will help to prevent drill slippage.
3. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
4. We recommend the use of a specialized drill bit when fixing accessories to tiled areas.

### **Supplied Mounting hardware:**

Screws and wall plugs

### **Mounting Instructions:**

1. Establish position for accessories, making sure there is sufficient room.
2. Hold the mounting post in the required position, (the distance between the posts are at owners' discretion. We suggest: 1 ½" - 2" from edge of glass.) Mark through with a pencil. When installing the second post, ensure the marks are horizontal by use of a carpenter's level.
3. Drill holes to a depth of 1" inch using a ¼" inch drill bit and insert the wall plugs so they are flush with the wall.
4. Fix the mounting post to the wall with the screws provided. Place the glass shelf onto the mounting post, making sure that the plastic set screw points directly downward before tightening.

### **Care Instructions:**

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.

If further assistance is required, please contact Customer Service at 1-888-825-7266 (9am-5pm EST)

