

Cat. No. UD701



INSTALLATION INSTRUCTIONS

Parts Included

• Push button pop-up with threaded body (1 pc.) • Nut • 1 Steel Washer • 2 Rubber Washers •

Parts Needed

•1-11/4" x 11/4" slip nut • 1-11/4" beveled washer • 1-11/4" x 8" or 12" tube extender

Note: The above parts are not needed if using FV washbasin traps: Model# U242 or U242.01. The necessary parts are included with the washbasin trap.

• Adjustable Wrench • Pipe Putty or Teflon Pipe Tape •

Pop-up Instructions

- 1. Put 1 rubber washer onto body, sliding it up to drain cap.
- 2. Place pop-up into sink drain hole.
- 3. Slide 2nd rubber washer onto body from below sink.
- 4. Slide metal washer onto body from below sink.
- 5. Thread nut onto body and tighten.

Connect drain to trap

- a. Slide the washer onto the tube extender.
- b. Slide the slip nut onto the tube extender.
- c. Place one end of the tube extender into the drain body.
- d. Slide the slipnut up the extender until it meets the drain body.
- e. Thread the nut onto the drain body and tighten until snug.

