161102

THE **Rubinet** FAUCET COMPANY

ASSEMBLY INSTRUCTION

2AHXL or C

THREE VALVE TUB & SHOWER






2AHXC


REMOVAL OF FIXTURE:


Always turn the water supply off before removing the existing fixture or disassembling a valve. Open all fixture handles to relieve water pressure and to ensure that the water has been successfully turned off.

CARE OF FIXTURE:


The use of warm water and a soft cloth is all that is required to clean Rubinet products. The patina of our living finishes (Oil Rubbed Bronze & Tuscan Brass) will change as a result of normal use. Applying Mineral Oil on occasion will create a softer look, subtle color changes and character.









THREE VALVE TUB & SHOWER



THREE VALVE TUB & SHOWER






FEATURES:

- Brass construction with choice of 21 finishes
- Two Lever or Cross handles, diverter (lever or cross)
- Quarter turn Ceramic Disk cartridges
- Flow Rate
 - Shower : 7.0 gpm @ 50 psi Tub : 7.0 gpm @ 50 psi

APPROVAL:

- AB1953 / NSF61
- ASME A 112.18.1
- CSA B125.1



CONTACT US:

If you need assistance with installation, replacement parts or have any questions regarding your Rubinet product, please call a Customer Service representative at: 905-851-6781 toll free 1-800-461-5901 or visit **www.rubinet.com**