### FEATURES:

- Brass construction with choice of 21 finishes - Single Handle Control cycles from Cold to Hot

- High temperature Limit Stop


- 20 psi minimum operationg pressure, 125psi maximum

# THE **Rubinet** FAUCET COMPANY

ASSEMBLY INSTRUCTION

2YETL

VALVE ONLY PRESSURE BALANCE WITH DIVERTER & STOPS



# 



2YETL

### **REMOVAL OF FIXTURE:**

Always turn the water supply off before removing the existing fixture or disassembling a valve. Open all handles to relieve water pressure and to ensure that the water has been successfully turned off.

### CARE OF FIXTURE:

The use of warm water and a soft cloth is all that is required to clean Rubinet products. The patina of our living finishes (Oil Rubbed Bronze & Tuscan Brass) will change as a result of normal use. Applying Mineral Oil on occasion will create a softer look, subtle color changes and character.

# CONTACT US:

If you need assistance with installation, replacement parts or have any questions regarding your Rubinet product, please call a Customer Service representative at: 905-851-6781 toll free 1-800-461-5901 or visit **www.rubinet.com** 

## VALVE ONLY PRESSURE BALANCE WITH DIVERTER & STOPS

