

10 Before calling for service

Problem	Possible cause	Solution
Completely fails to work	Is there a power cord outage? Is the powercord unplugged? Are you sitting on the seat correctly?	Check for a power cord failure or a tripped breaker Plug the power cord in properly Sit on the seat completely
Water does not spray	Is the water shutoff valve closed? Is the strainer clogged? Are the nozzles clogged? Is the water purifying filter clogged?	Check for any water leaking or dripping Clean the strainer Clean the nozzles Change the water purifying filter
Water is leaking or dripping	Check for all hoses are tightened properly	If water is still leaking or dripping, contact to your dealer
Seat, water or air is not enough warm	Is the temperature set to OFF? Is appliance used in economy mode such a cold weather?	Reset the temperature Release the economy function

11 Specifications

Item	UB-6035R
Standard power supply	AC 120V 60Hz 660W
Water supply	Way of connection Direct connection to tap water
	Water pressure 0.08MPa ~ 0.75MPa
Cleaning	Spray for cleansing 900 ± 100ml/min
	Spray for bidet 900 ± 100ml/min
	Water capacity 800 ml
	Spray temperature Room Temp ~ 40°C (104°F)
	Heater capacity 600W
	Safety feature Thermal switch, Temperature fuse, Floating switch
Dry	Air temperature Room temp ~ 60°C (140°F)
	Heater capacity 250W
	Safety feature Temperature fuse
Heated seat	Seat temperature Room temp ~ 40°C (104°F)
	Heater capacity 55W
	Safety feature Temperature fuse
Deodorization method	Catalytic filter
Circuit breaker	Within 15mA 0.03 second
Length of power cord	1.2m
Dimensions	(W)392mm X (L)520mm X (H)143 (W)15.43inch X (L)20.47inch X (H)5.62inch
Weight	4.4Kg(9.7lbs)

※ Recommended water supply pressure are 0.1MPa-0.69MPa

※ The minimum available water supply pressure is 0.08MPa-0.1MPa, however under 0.1Mpa pressure, water spray pressure might not be enough strong.