



ROHL DECORATIVE LUXURY AIR ACTIVATED SWITCH BUTTON ONLY FOR WASTE DISPOSAL

ROHL Kitchen Accessories

AS525

FEATURES

- Traditional styling
- Remote on/off air switch button for activating continuous feed waste disposals
- Transmitter button with escutcheon, base and fastening nut included
- 1 1/4" cutout, 2" max. installation depth on deck or wall
- Escutcheon and button made of brass
- Does not come with control box, button only
- Button and escutcheon adhered to base
- Matches ROHL finishes
- Includes ROHL branding on top of button

COLORS/FINISHES

- Polished Chrome
- Polished Nickel
- Satin Nickel
- Inca Brass
- Tuscan Brass
- English Bronze

WARRANTY

- Limited Lifetime*
- * No Warranty on Tuscan Brass Finish (TCB)

