



CAUTION - RISK OF SHOCK Disconnect Power at the main circuit breaker panel or main fuse box before starting and during the installation.



- Find the appropriate threaded holes on mounting strap that 1) align with hole distance in canopy. Thread mounting screws into threaded holes starting from outlet box side.

 Attach mounting strap to outlet box with strap mounting
- 2) screws. Mounting strap can be adjusted to suit position of fixture.
- Grounding instructions: (See Illus. A or B)
 - On fixtures where mounting strap is provided with a hole and two raise dimples. Wrap ground wire from out let box around green ground screw, and thread into
- On fixtures where a cupped washer is provided. Put ground wire from outlet box under cupped washer and green ground screw and thread screw into hole in B) mounting strap


If fixture is provided with ground wire. Connect fixture ground wire to outlet box ground wire with wire connector, after following the above steps. Never connect ground wire to black or white power supply wires.



Make wire connections. Reference chart below for correct connections and wire accordingly.

commodition and who accordingly.	
Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)



- Push fixture to wall carefully passing mounting screws with holes in canopy. Make sure all wires are inside canopy and do not get pinched between wall and canopy of fixture. Thread lockup knobs onto mounting screws. Tighten to

- secure lockup knobs to secure fixture to wall.

 Lower the glass down to the fixture, and set over the socket. Thread socket ring onto the socket. Tighten socket ring to secure the glass in place. DO NOT OVER TIGHTEN 8)
- Insert recommended bulb(s) (Not supplied) 9)

- INSTRUCTIONS FOR MOUNTING FIXTURE OUTDOORS AND/OR IN WET LOCATIONS.

 Mounting surface should be clean, dry, flat and 1/4" larger that the canopy on all sides. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- With silicone caulking compound, caulk completely around where back of canopy meets the wall surface to prevent water from seeping into outlet box.

Date Issued: 10/27/16 IS-45595-CB