
WATERMYRK

FEATURES

- ¼ Turn ceramic disc cartridges
- Hand Shower Flow Rate: 2.0 gpm at 45psi
- Solid Brass Construction
- Warranty:
 - Limited lifetime warranty (residential use)
 - One year (commercial use)

• Some systems may require a remote pressure balance valve




ITEM NO.	PART NUMBER	QTY.
1	ELMNT-HNDL-INSRT (SCALLOP OR BRIDGE)	2
2	ELMNT-HNDL-BASE	2
3	#8-32 SOCKET; CUP POINT; 3/16" LENGTH	4
4	#8-32 FLAT HEAD SCREW; 7/16" LENGTH	2
5	SH-TIT30	1
6	DS-4079	1
7	M5 PAN HEAD SCREW; 16MM LENGTH	4
8	.75NPS-TO-SWEAT- ADAP	2
9	ELMNT-HNDL-CVR	2
10	22-8.3-BODY	1
11	22-8.3-TBSPT-AERTR- SHLL	1
12	22-8.2-LEG	2
13	22-8.2-ESC	2
14	AS568 - 127 O-RING	2
15	22-8.2-MNTNG-RBBR- WSHR	2
16	22-8.2-MNTNG-WSHR	2
17	22-8.2-MNTNG-NUT	2

1. Carefully remove all parts from the box.

- 2. Assemble leg escutcheons (13) with the tub filler legs(12)
- 3. Screw hand shower hose (25) onto hand shower (24) and onto tub filler body (10)
- 4. Insert tub filler legs into deck
- 5. Insert mounting washers (15 and 16) and mounting nut with screws (17 and 7) onto the tub filler legs (12)
- 6. Screw ¾ " NPS female to sweat adapter (8) onto tub filler legs (12)
- 7. Sweat lines to sweat adapter

WATERMYRK

Dimensions:



IMPORTANT INSTALLATION INFORMATION

- USE TEFLON TAPE OR PIPE SEALANT FOR THREADED CONNECTIONS
- DO NOT USE PLUMBER'S PUTTY ON ANY OF THE BRASS COMPONENTS This will cause the finish to tarnish and void the warranty. A non-corrosive Alkoxy Silicone is recommended.
- DURING SWEATING OF LINES DO NOT OVERHEAT CASTING Overheating may cause damage to internal mechanism
- COPPER ADAPTORS MAY BE REQUIRED TO COMPLETE YOUR INSTALLATION

For technical support, please call 718-257-2800