

PB-3524 INSTALLATION

Install wall nipple (provided by plumber) through Slip bar into the top of the lower post. Remove post hole in wall. Tighten lower post assembly onto cap and tighten set screw on to bar to hold it in nipple place. Slip lower post cap to cover set screw hole 1. 2. WALL NIPPLE O-RING SET SCREW Line up hole in wall with hole in the top of the bar. Slip top post over bar. Install dry wall screw through Install wall anchor into wall bar. Ensure larger hole in bar is facing away from the wall so the head of the screw is inside the bar. Slip the top post cap over the post. 3. 4. LARGE HOLE