

# INSTALLATION GUIDE (TOPMOUNT/DROP-IN/SELF RIMMING)


Required Tools



## ATTENTION

Please read the warning and homeowner section before unboxing. It is always recommended to use a professional when installing a new topmount sink.

**Please observe all state and local building and plumbing codes.**



## WARNING

Before installation, remove your sink from its packaging. **Please use caution. We recommend using gloves to prevent injury. The edge of the sink rim can be sharp and could cause minor cuts.** Please inspect your product for any damage that may have occurred during shipping. If the product was damaged in the shipping process or your product needs to be returned for another reason, it must be in the original packaging. If the product is not returned with the original packaging you may not be eligible for a refund of the purchase price. Return fees may apply.

Please contact your dealer for more information.

## HOMEOWNERS

Please read before installation.

## NEW INSTALLATION

When preparing for installation, it is recommended that you consult with a professional

## REPLACEMENT

If replacing a pre-existing hole, make sure that the new model you have chosen fits the existing hole.


## Step: 1

### COUNTERTOP PREP

When preparing the template take care not to scratch or damage your countertop.

**TEMPLATE:** Place template in desired location to allow for proper clearance. Using a pencil trace the template on to the countertop (A)

**NO TEMPLATE:** If no template is provided, flip the sink over and trace the outside edge. Remove the sink. Measure from the outer rim to the first rail. Use this measurement to create a cut line in from the original rim outside line.




## Step: 2

### CUTTING THE HOLE

After marking the template, cut a pilot hole on the inside of the template mark cut line. Use the appropriate cutting tool for the solid surface material you have selected. Cut on the outside edge of the mark.

Support the cutout until the cut is complete or it could cause damage to the countertop.

**(Professional fabrication is recommended)**




## Step: 3

### INSTALLATION

After the cut out has been made, clean the surface of the countertop. Apply a continuous bead of silicone sealant / adhesive specifically designed for plumbing applications around the rim of the cut out.

**BE ADVISED:**  
Your installer might use a different installation method.




## Step: 4

**DETERMINE INSTALLATION METHOD USING THE PICTURES BELOW**

### INSTALLATION (U BRACKET)

- Put the clip together as shown in diagram (A) Insert the clip into the sink rim channel, Placing the head of the screw into the channel. Place clips each in the front and back of the sink. (A)
- Evenly space the clips around the sink for better adhesion. The clip assembly needs to be positioned parallel to the channel (B)
- Carefully place the sink into the pre-cut hole. Make sure it is properly aligned and seated. Press firmly around the edge of the sink.
- Rotate the clamp 90 degrees parallel to the channel and tighten the screw clockwise from the center of the clip. We recommend using a long screw driver. (C)




### INSTALLATION (L BRACKET)

Place the sink upside down. Hold the clip with your thumb on the plastic hinge. With the tip of your thumb facing the bowl, firmly insert the clip as shown below. Make sure the sharp teeth are facing toward the outer edge of the sink. Stagger clips around bowl. 2 on each side. **Use extreme caution while inserting clips as the teeth are sharp and may cause injury.** Place the sink carefully into the cutout opening and be sure it is properly seated. Make sure the sink rim covers sealant all around. Then press down firmly around perimeter of the sink rim. When the sink is seated correctly, tighten screws, and remove any excess sealant.

L BRACKET DIAGRAM

U BRACKET DIAGRAM



# INSTALLATION GUIDE

Required Tools




## ATTENTION

This product requires professional installation. Please provide your countertop fabricator with this information. Please observe all state and local building and plumbing codes.


### \*\*TEMPLATE/GUIDE\*\*

The template provided is to be used as a guide for cutting. Due to installation preference, some customization will be required. Please contact the manufacturer if a .DXF file is required.



## WARNING

Before installation, please inspect your product for any damage that may have occurred during shipping. If the product was damaged in the shipping process or your product needs to be returned for another reason, it must be in the original packaging. If the product is not returned with the original packaging you may not be eligible for a refund of the purchase price. Return fees may apply. Please contact your dealer for more information.



## HOMEOWNERS

Please read before installation.

## NEW INSTALLATION

When preparing for installation, it is recommended that you consult with your countertop fabricator as to your installation preference. **When preparing the template for installation, a 1/4" overhang is recommended to provide a clean transition from countertop to sink.** The overhang will hide any sign of the silicone adhesive.

## REPLACEMENT


If replacing a pre-existing hole, make sure that the model you have chosen is larger than the existing hole. This will allow for any adjustments that might be needed for the installation process.

## INSTALLATION PREFERENCE


**FLUSH MOUNT:** The countertop is flush with the sink.

**OVERHANG:** The countertop is positioned over the sink bowl by a set amount. (Typically 1/8" to 1/4")

### FLUSH



### OVERHANG




## Step: 1

### COUNTERTOP PREP

When preparing the template take care not to scratch or damage your countertop.

1. Place template in desired location to allow for proper bowl and faucet clearance. If using a backsplash with your countertop, make sure that it is accounted for during your measurements.
2. If choosing a flush installation, use the designated line on the template. If an overhang is desired, customization of the template will be required to achieve the designated overhang.




## Step: 2

### CUTTING THE HOLE

When the the template is finished, take a moment and place it on the actual sink. The template will represent the countertop sink hole. Make sure that the template achieves the result you desire.

1. After marking the template, cut a pilot hole on the inside of the template mark. Use the appropriate cutting tool for the solid surface material you have selected. Cut on the inside edge of the mark.

**(Professional fabrication is recommended)**



## Step: 3

### INSTALLATION


#### ANCHOR HOLES:

After the sink hole has been made, evenly space clips around the sink where accessible. Measure the anchor hole by positioning a clip along the edge of the sink hole in the desired location and place a mark in the farthest clip hole location from the edge.

**BE ADVISED:**  
Your fabricator might use a different installation method.

#### PREP THE SINK:

Apply a continuous bead of silicone sealant / adhesive specifically designed for plumbing applications.



## Step: 4

### INSTALLATION

After you have confirmed that the sink lines up correctly within the existing hole cut-out, it is now time to install the sink.

1. Center the sink on the underside of the countertop sink hole. You will need to brace the sink in place during fitting.
1. Using the new hardware or existing hardware, loosely tighten the clips with the angled side facing down. After final adjustments have been made, tighten clips.
3. **Clean any excess sealant from the inside rim of the sink immediately** and prepare for plumbing.

