

MODEL: 601224  
602523

INSTALLATION SHEET

ACCESSORIES

### MATERIALS NEEDED:

PHILIP SCREWDRIVER  
LEVELING TOOL  
DRILL

### MATERIAL PROVIDED:

(2) WOOD SCREWS  
(2) ANCHORS


**ALL WIRING SHOULD BE DONE BY A QUALIFIED LICENSED ELECTRICIAN.**

**WARNING:** To reduce the risk of electrical shock, shut off power before wiring the cabinet.

**CAUTION:** Requires 120V 20AMP circuit.

**CAUTION:** The LED mirror must be wired to a 20AMP GFI (ground fault interrupter) circuit breaker when used in bathrooms and all other locations required by the national electric code.


### WIRING DIAGRAM:



**Figure 1.**

**STEP 1:** Determine the ideal location of your new LED mirror. Make sure mirror has enough clearance from faucet and ceiling.

See Figure 1.



MODEL: 601224  
602523


INSTALLATION SHEET

ACCESSORIES

**STEP 2:** Determine location of wall cleat. Make sure to use the leveling tool to ensure the pilot holes are level. Drill pilot holes into the wall.

See Figure 2.

**Figure 2.**




**STEP 3:** Secure the anchors in the wall, and then fasten the screws provided into the anchor.

**STEP 4:** If the mirror is not flush to the wall it is recommended to cut an opening in the wall and hide your wires inside the wall.

See Figure 3.

**Note:** Connect the defogger and LED wires per the wiring diagram.

**Figure 3.**



**STEP 5:** Secure the cleat in the back of the mirror to the wall cleat on the wall.

See Figure 4.

**Figure 4.**

