

**CAUTION – RISK OF SHOCK –**

Disconnect Power at the main circuit breaker panel or main fuse box before starting and during the installation.

**INSTRUCTIONS**


For Assembling and Installing Fixtures in Canada  
Pour L'assemblage et L'installation Au Canada

- 1) Thread small threaded pipe into end of small loop. Pass threaded pipe on small loop up through hole in canopy.
- 2) Thread lockwasher onto end of threaded pipe protruding from inside canopy.
- 3) Thread hexnut onto threaded pipe protruding from inside canopy.
- 4) Thread one of the small loops onto the top of the fixture body.
- 5) Attach open end of one chain link to loop on top of fixture body. Attach other open end of that chain link to one end of chain.
- 6) Attach open end of one chain link to small loop on canopy. Attach other open end of that chain link to other end of chain.
- 7) Weave fixture wires through chain links no more than 3 inches apart.
- 8) Pass fixture wire through hole in small loop on canopy and through hole in canopy.
- 9) Find the appropriate threaded holes on mounting strap. Assemble mounting screws into threaded holes.
- 10) Attach mounting strap to outlet box. (Screws not provided). Mounting strap can be adjusted to suit position of fixture.
- 11) Make wire connections. Reference chart below for correct connections and wire accordingly.

- 18) Carefully raise glass/trim up to fixture . The smaller opening of the glass should be the top. Pass the sockets and fit top edge of trim inside fixture roof.
- 19) Thread the coupling onto the protruded threads of the support tube below the bottom trim plate.
- 20) Thread the threaded pipe into the bottom of the coupling. Secure into place by tightening the hex nut until it meets the coupling.
- 21) Raise the bottom trim, slip over threaded pipe, and fit into the bottom of the glass trim.
- 22) Thread the finial onto the threaded pipe. Tighten finial to secure the bottom trim into place. (If the finial isn't flush with the bottom trim: remove and make adjustments to the threaded pipe to shorten the length of protruded threads)

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

\*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)



- 12) Push fixture to ceiling, carefully passing mounting screws through holes in canopy.
- 13) Thread lock-up knobs onto mounting screws. Tighten knobs to secure fixture to ceiling.
- 14) Insert recommended bulbs. (Not supplied)
- 15) Thread the support tube into the bottom of the wire housing until the rib on the tube meets the housing.
- 16) Raise the bottom trim plate up to meet the bottom glass trim bracket. Adjust the hexnut on the support tube until it touches the top of the trim plate.
- 17) Thread screws up through holes of the trim plate and into holes of the glass/trim bracket. Tighten screws to secure plate into place.

