

CAUTION – RISK OF SHOCK –

Disconnect Power at the main circuit breaker panel or main fuse box before starting and during the installation.

INSTRUCTIONS


For Assembling and Installing Fixtures in Canada
Pour L'assemblage et L'installation Au Canada

- 1) Slip hole in bottom trim over the bottom of the lower stem. Thread the finial onto the protruding threads of the lower stem.
- 2) Adjust the trim until the back is parallel with the canopy and top trim. Tighten the finial to secure the trim to the fixture.
- 3) Insert recommended bulbs (Not supplied)
- 4) Attach each long bead strands to holes inside top trim (you may need to pinch with needle nose pliers to secure hook) Attach other end onto holes of top side of center ring.
- 5) Attach each end of short bead strands onto holes from bottom side of center ring (you may need to pinch with needle nose pliers to secure hook). Attach other end onto holes of top side of bottom trim.
- 5) Attach each end of short bead strands onto holes from bottom side of center ring.
- 6) Thread hexnut onto threaded pipe so that 5 threads are exposed below hexnut. From underside of mounting strap, thread long end of threaded pipe into hole in mounting strap until hexnut touches mounting strap. Tighten hexnut against mounting strap.
- 7) Thread second hexnut onto other end of threaded pipe. Tighten hexnut up against mounting strap.
- 8) Attach mounting strap to outlet box.

- 9) Make wire connections. Reference chart below for correct connections and wire accordingly.

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)



- 10) Push fixture to wall, carefully passing threaded pipe through hole in canopy. Care should be taken to insure that wires are completely inside canopy.
- 11) Thread threaded cap on to threaded pipe. Tighten threaded cap to secure fixture to wall.

