

MOANA



# PULSE

SHOWERSPAS

**Moana ShowerSpa**  
**Model #1044-SSB**  
**Owner's Manual**



# Moana ShowerSpa Model #1044-SSB

## Please Read The Following Instructions **COMPLETELY** Before Beginning!

Our goal is to ensure your installation goes smoothly and safely. Please read these instructions carefully and follow recommendations for plumbing and mounting. **After reading instructions, if you determine you do not have the necessary skills and/or tools, we recommend that a licensed plumbing contractor complete the installation.**

***If you encounter any problems during installation  
CALL TECHNICAL SUPPORT  
TOLL FREE at 888-785-7320  
before returning your ShowerSpa to the store***

### You Will Need The Following Tools

Soft pencil or felt pen to mark tile

Safety glasses

Tape measure


Level

Reciprocating saw w/ metal cutting blade (Sawzall®)


Adjustable wrench

Drill/Driver (Preferably cordless)


¼" Masonry drill bit



# Product Dimensions



# Parts Legend



No.	Name	Quantity
1	ShowerSpa body	1
2	Screw	4
3	Mounting bracket	2
4	Wall anchor	4
5	90° elbow/Supply line	1
6	Rubber washer	3
7	Nut	1
8	Silicone washer	1
9	Hand Shower holder	1
10	Hand Shower hose	1
11	Hand shower	1

# Assembly

*Before installing your ShowerSpa, some assembly is required*

## Hand Shower Holder Assembly

1. Insert hand shower holder (9) into hole located on side of ShowerSpa and secure with silicone washer (8) and nut (7).
2. Secure nut (7) with adjustable wrench if needed.
3. Attach supply line (5) with rubber washer (6) installed to the hand shower holder (9). Securely tighten to ensure no leaks. (Caution - do not overtighten)

## Connecting The Hand Shower

1. Insert washer (6) into hexagon shaped end of hand shower hose (10) and attach to threaded outlet of hand shower holder (9). Do not overtighten.
2. Insert washer (6) into tapered end of hand shower hose (10) and attach to hand shower (11). Insert hand shower into holder.

# Installation—New Construction

## Extensive Remodel—New Finished Wall Surface

1. Prior to sheetrock, stub-out  $\frac{1}{2}$ " hot and cold supply lines beyond finished wall surface, 3" on center. For best results, attach 90° brass fittings (available at most hardware stores) to the stub-outs maintaining  $\frac{1}{4}$ "– $\frac{1}{2}$ " of space between the fitting and finished wall. The open end of the 90° brass fittings should point down so the supply lines attach parallel to the wall.<sup>1</sup>
  2. The height of the stub-outs is completely dependent upon the desired mounting height of your Moana ShowerSpa. For a person 5'8"–6'2" we recommend the stub-outs be 38" from finished floor.<sup>2</sup>
  3. Before installation, make certain that water is completely turned off to both hot & cold supply lines of the shower.
  - 4a. Mark location of holes for top mount (3), making sure holes are level. For a person 5'8" – 6'2", we recommend placing holes of upper mount at approx. 61  $\frac{1}{4}$ " above finished floor.
  - 4b. To determine location for lower mount (3) measure distance between indents on bottom edge of horizontal mounting bars on back of ShowerSpa. Using this distance, measure down from holes in upper mount to obtain location of holes in lower mount making certain mounts are plumb.
  - 4c. Use mounts to mark location of holes for each mount.
- NOTE**—Before drilling holes for the brackets, make certain the ShowerSpa will rest flat against finished wall surface at the desired mounting height with the supply lines connected.
5. Drill  $\frac{1}{4}$ " holes through wall surface using a masonry bit. Drill slowly through wall surface to avoid cracking and chipping. Insert anchors (4) and securely screw brackets to wall. Before connecting hot and cold supply lines, hang ShowerSpa on wall, check the height and make sure ShowerSpa is flush against wall with a secure fit.
  6. Connect hot and cold water supply lines to stub-outs—**DO NOT OVERTIGHTEN**. Before mounting the ShowerSpa, check fittings to make sure they are secure. Turn on water and check for leaks. When fittings are leak-free, mount ShowerSpa on wall.
  7. **OPTIONAL**—Seal around body of ShowerSpa with a bead of silicone. **DO NOT SEAL BOTTOM**.<sup>1</sup> Additional fittings or longer supply lines may be necessary depending on your specific situation.

<sup>2</sup> The desired mounting height of ShowerSpa determines height of the  $\frac{1}{2}$ " stub-outs. The stub-outs must be located at a height allowing supply lines to be connected and body of ShowerSpa to rest flat against finished wall.

<sup>3</sup> The mounting height may vary depending on several factors (i.e. location of supply lines, interference from ShowerSpa plumbing, old valve access area, personal preference, etc.)

# Installation—Retrofit

## Existing Shower Replacement

**NOTE**—In a remodel in which you are not replacing the finished wall surface (tile, or backing material) it is advisable to purchase a PULSE ShowerSpa model that covers the location of existing valve assembly—either single handle or two-handle type. If your PULSE ShowerSpa model does not cover this area, you will need to either choose another PULSE ShowerSpa model that does or make necessary repairs with appropriate materials (i.e. wallboard, tile, fiberglass, etc).

1. **TURN OFF WATER SUPPLY TO SHOWER.** Typically there is a gate valve where the water main enters the house. Turning the water valve off at hot water tank does not turn off cold water supply line.
2. Make certain that water is completely turned off to both the hot & cold supply lines of the shower. Turn shower valve on, both hot and cold, to verify water supply is **OFF**. Open a sink faucet in the bathroom in which you are installing the ShowerSpa to relieve any pressure and help adequately drain the shower supply lines.
3. Remove handle(s) and trim cover(s) of your existing valve exposing valve body in wall.
4. Locate hot and cold supply lines entering valve. Using a reciprocating saw with sharp metal saw blade, cut existing valve out, preserving threads of the supply lines entering valve. You should also cut the riser within wall supplying the existing showerhead. Carefully twist and remove valve.
5. Unscrew old showerhead from shower arm and then unscrew shower arm from the wall.
6. Water lines must be extended outside of wall cavity, 4" on center. For best results, attach 90° brass fittings (available at most hardware stores) to the stub-outs maintaining ¼"–½" of space between the fitting and finished wall. The open end of the 90° brass fittings should point down so the supply lines attach parallel to the wall.<sup>4</sup>
7. Make certain that when you connect to the stub-outs they **DO NOT INTERFERE** with the backside of the ShowerSpa after mounting.<sup>5</sup>
8. Mark location of holes for the wall mounts, making sure holes are plumb. For a person 5'8"–6'2" tall we recommend placing holes of upper bracket at 61 ¼" from finished floor height.<sup>3</sup> Measure distance between horizontal mounting bars located on back of ShowerSpa. Using that distance, measure down from upper wall mount holes to determine exact location of lower wall mount holes (approx. 33½"). Before drilling holes for the brackets, make certain the ShowerSpa will rest flat against finished wall surface at the desired mounting height with the supply lines connected.
9. Drill ¼" holes through wall surface using a masonry bit. Drill slowly through wall surface to avoid cracking and chipping. Insert anchors and securely screw brackets to wall. Before connecting hot and cold supply lines, hang the ShowerSpa on wall, check the height and make sure the ShowerSpa is flush against the wall with a secure fit.
10. Connect hot and cold water supply lines to stub-outs—**DO NOT OVERTIGHTEN**. Before mounting the ShowerSpa, check fittings to make sure they are secure. Turn on water and check for leaks. When fittings are leak-free, mount ShowerSpa on wall.
11. **OPTIONAL**—Seal around body of ShowerSpa with a bead of silicone. **DO NOT SEAL BOTTOM.**

<sup>3</sup> The mounting height may vary depending on several factors (i.e. location of supply lines, interference from ShowerSpa plumbing, old valve access area, personal preference, etc.)

<sup>4</sup> Additional fittings or longer supply lines may be necessary depending on your specific situation.

<sup>5</sup> The mounting height can vary depending on several factors (i.e. location of supply lines, old valve access area, interference from ShowerSpa plumbing, personal preference, etc).

# Usage

## Pressure Balance Mixing Valve

The Moana ShowerSpa is equipped with a cUPC® pressure balance mixing valve to adjust water flow and temperature. The valve automatically adjusts to changes in water pressure (i.e. someone flushes a toilet), keeping your temperature constant and preventing accidental scalding. To turn on the ShowerSpa simply raise the handle until the desired flow rate is achieved. Rotate to the right to decrease temperature and rotate to the left to increase temperature.

## Brass Diverter

The brass diverter is used to change between ShowerSpa functions. Simply rotate the diverter knob either direction to select the desired function—shower head, hand shower, or body jets.

## Hand Shower

The brass hand shower delivers a satisfying power-spray pattern with a 1.5M - 1.8M stainless steel stretch hose.

## Body Jets

There are three single-function embossed body jets that provide soothing spray.

# Care and Maintenance

Always blot dry any water from the surface of your ShowerSpa. To protect your ShowerSpa from hard water stains and mineral deposits, use an auto spray wax periodically and wipe down your ShowerSpa after each use. Allowing water to evaporate on the surface can lead to a buildup of mineral deposits. Cleaning with a damp, non-abrasive sponge and drying with a clean soft cloth should help keep your ShowerSpa looking beautiful. Showerhead, handshower, and body jets have silicone rubber tips that should be rubbed periodically to help break up any mineral deposits. This will ensure long lasting, Spray-Straight™ performance.

## R E M E M B E R

*NEVER use any abrasives or harsh cleaners!*

*Clean with mild soap and water ONLY!*

*To keep your ShowerSpa in pristine condition,  
DRY AFTER EACH USE!*

# Manufacturer's Limited Warranty

PULSE ShowerSpas, Inc. warrants that all ShowerSpas are free from defect in workmanship and/or materials for a period of three years from the date of purchase. This warranty extends to the original purchaser only and is non-transferable.


This warranty does not cover, and PULSE ShowerSpas will not pay for any conditions, malfunctions or damages resulting from (1) normal wear and tear, improper installation (whether performed by a contractor, a service company or the consumer), improper maintenance, misuse, abuse, negligence, accident or alteration; (2) the use of abrasive, caustic or "no-rinse" cleaning agents; (3) the use of the product in any manner contrary to the product instruction; (4) any condition in the home such as excessive water pressure or corrosion.

Should any ShowerSpa be determined by PULSE ShowerSpas, Inc. to be defective in normal residential use, at the option of PULSE ShowerSpas, Inc., such product shall either be replaced or repaired and returned to the customer free of defects. The consumer shall give notice of any defects to PULSE ShowerSpas, Inc. within thirty days of discovery of such defect.

Proof of purchase (original sales receipt) must be provided to PULSE Shower Spas, Inc. with all warranty claims. PULSE ShowerSpas, Inc. is not responsible for any labor charges, removal charges, installation or other consequential costs. In no event shall the liability of PULSE ShowerSpas, Inc. exceed the purchase price of the ShowerSpa.

Some states/provinces do not allow limitations of how long an implied warranty lasts or the exclusion or limitation of such damages, so these limitations and exclusions may not apply to you. This warranty gives the consumer specific legal rights. You may also have other rights that vary by state/province.

Follow manufacturers recommended installation. Use caution with children under ten years of age. Do not use ShowerSpa as a support device. Do not use harsh chemicals or abrasives when cleaning. Turn water supply off when servicing your ShowerSpa.



**PULSE**  
SHOWERSPAS

Pulse ShowerSpas, Inc. ~ 297 Anna Street ~ Watsonville, CA 95076 ~ 888.785.7320  
info@pulseshowerspas.com ~ www.pulseshowerspas.com ~ support@pulseshowerspas.com